

Oxy Brite L

Liquid Color-Safe Laundry Bleach

Product Number 4447

Description

This blend of oxygen bleaching agents is safe to use on colored fabrics. Helps to brighten and destain without the harsh effects of chlorine releasing bleaches. Helps reduce the chance of stains caused by an iron loaded water supply. Can be used with enzyme detergent systems.

Directions

Product can be added to wash cycle, or to a separate bleach cycle immediately following the wash cycle. Ideal pH of bleach cycle should be between 11.0-12.0 and the water temperature above 150°F. Use 3-4 ounces per 50 pounds of linen.

Technical Data

| | | | |
|------------------|--------|-----------------------|-----------------|
| Form | Liquid | pH (1% solution)..... | 4.0-4.5 |
| Color | Clear | Viscosity | Light |
| Scent..... | N/A | Density | 8.94 lbs/gallon |
| Solubility | Rapid | | |

Product Category: Laundry Systems/Liquids

DOT Shipping Information: Hydrogen Peroxide, Aqueous Solutions, 5.1, UN2984, III



DANGER

HAZARDS: May cause fire or explosion; strong oxidizer. Causes severe skin burns and eye damage.

PRECAUTIONS: Keep away from heat/sparks/open flames/hot surfaces. - No smoking. Keep away from combustible materials. Take any precaution to avoid mixing with combustibles. Wash hands thoroughly after handling. Wear protective gloves/protective clothing/eye protection/face protection. Wear fire/flame resistant/retardant clothing.

RESPONSE/FIRST AID: Have product container or label with you when calling poison control center or physician. **IF**

SWALLOWED: Rinse mouth. Do NOT induce vomiting. Immediately call a POISON CENTER or doctor/physician. **IF IN**

EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Call a poison control center or physician for treatment advice. **IF ON SKIN (or hair):** Remove/take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse. **IF INHALED:** Remove victim to fresh air and keep at rest in a position comfortable for breathing. Seek medical advice if feeling unwell.

STORAGE & DISPOSAL: Store locked up. Dispose of contents/container to trash after rinsing container.



Partners In Productivity

PDQ Manufacturing, Inc.

201 Victory Circle | Ellijay, GA 30540 USA | (800) 248-2401 | Fax: (706) 636-1849 | www.pdqonline.com